

## Customer Instructions Sno-Cone Machine



**Warning:** Never put your fingers or any object into the shaver while the machine is plugged in. Be sure machine is grounded to prevent shock. Watch children around machine-blades are sharp!

### Operating Instructions

1. The Sno-Cone machine can use ice cubes or block ice. If you are using block ice break it into pieces approximately 3 to 4-inches in size.
2. Fill hopper to within an inch of the top with ice. The larger the pieces of ice, the better the snow.
3. Switch the motor on and wait for it to come to full speed.
4. Push the plunger handle down against the ice in the hopper. Apply firm & even pressure to make the best snow. Practice will allow you to gauge when to stop pressing. This allows the ice in the hopper to resettle against the shaver head. Too much pressure will result in snow that is coarse; too little pressure will make the snow mushy.
5. Never use any foreign or metallic objects in the hopper, or around the shaver area-including ice picks. This could result in 1.) bits of inedible objects getting into the ice, resulting in a ruined batch of ice or 2.) damage to the blades, which may incur costs to you.

#### Disclaimer:

*These instructions are intended as a helpful reminder. They do not replace the full operating instructions found in the owners manual, which is available at the rental counter.*

**A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area  
If you like this piece of equipment, inquire about purchasing it !**

If equipment does not work properly, notify office at once -

• Phoenix, 602-955-5100 • North Valley, 602-992-1150 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •