

Customer Instructions FOG MACHINE



Warning: Always make sure there is enough fog fluid in the tank before turning the machine on. Activating the pump without fluid can cause damage to the machine. Customer is responsible for any damage to the machine.

Use in a well ventilated area. Steam from nozzle is hot. To avoid injury, keep nozzle at least 2 feet away from people.

Please note: This is not a “low lying” fog machine

Operating Instructions

1. Be sure cord is plugged into a grounded outlet ONLY. Plug the remote control into rear of machine.
2. Fill reservoir with approved fog fluid purchased from A to Z only.
3. Close cap tightly. Push clear plastic feeder tube down through the cap.
4. When the indicator light on the controller on the machine goes on, the machine is ready for use. This will take approximately **30 minutes**.
5. To use the timer mode, press the “TIMER” button. Adjust the “DURATION” knob for the length of fog burst. Adjust “INTERVAL” knob for length of time between fog bursts.
6. Clean any residue off of the machine before returning.

Disclaimer:

These instructions are intended as a helpful reminder. They do not replace the full operating instructions found in the owners manual, which is available at the rental counter.

**A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area
If you like this piece of equipment, inquire about purchasing it!**

If equipment does not work properly, notify office at once -

• Phoenix, 602-955-5100 • North Valley., 602-992-1150 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •