Customer Instructions DUNK TANK



Warnings: BE SURE TO READ & UNDERSTAND ALL OF THE RULES OF OPERATION POSTED ON THE SIDE OF THE DUNK TANK BEFORE USE!

Set Up Instructions

- 1. Unhook the trailer, safety chains & lights from the towing vehicle.
- 2. Using the tow bar as a handle, carefully roll the tank to a <u>level</u> set-up area.
- 3. Remove the tow bar by first taking out the 2 pins that attach it to the frame, and then unplugging the tow lights.
- 4. Carefully lift the tank from the top of the cage to the upright position.

 AT LEAST 2 PEOPLE ARE REQUIRED TO DO THIS SAFELY.
- 5. Unhook the rubber straps & chain from the cage, & unfold the frame. The chain will now be used to secure the frame to the tank unit to keep the frame from pushing forward.
- 6. On the bottom of the backstop, you will find a slot through which the supplied stake should be driven into the ground to secure the frame.

BE VERY CAREFUL WHEN STAKING, WE ARE NOT RESPONSIBLE FOR ANY DAMAGE, INCLUDING SPRINKLER DAMAGE.

- 7. Slide the target arm in between the latch & the bracket under the seat. The opposite end of the target arm now goes thru the hole in the tarp. Slide the pin in the middle of the target arm into the slot to hold it in place.
- 8. Screw the round target plate onto the target arm in front of the tarp.
- 9. Be sure to close the drain valve located at the bottom of the tank, and fill the tank.

Take Down/Towing Instructions

- 1. Open the drain valve and drain the tank. A discharge hose is recommended to direct the water.
- 2. Remove the target plate & target arm, and disconnect the chain.
- 3. Remove the stake from the bottom of the frame, & fold the small tarp inwards onto the large tarp. Now fold the entire frame up to the cage & secure it to the cage with the 2 rubber straps & the chain.
- 4. From the ladder side (back) of tank, tilt the tank back slowly until it is resting on the tires.

 AT LEAST 2 PEOPLE ARE REQUIRED TO DO THIS SAFELY.
- 5. Slide the tow bar back into the frame, put the 2 pins back in place & plug in the lights.
- 6. Re-secure the dunk tank to the towing vehicle, making sure to install the tongue lock, cross the safety chains & check the lights.

BE SURE TO RETURN THE TARGET PLATE, TARGET ARM & SOFT BALLS. YOU ARE RESPONSIBLE FOR THEIR RETURN.

A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area If you like this piece of equipment, inquire about purchasing it!

If equipment does not work properly, notify office at once -

• Phoenix, 602-955-5100 • North Valley, 602-992-1150 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •